

# Eliminator Next Gen

## Quick Start Guide

### 1.) Power

Press and hold the Right “STAGE” button to **turn on** the *Eliminator Next Gen*. From the Main Menu, press and hold the Right and Left “STAGE” buttons to **turn off** the *Eliminator Next Gen*. See Figure 1.

### 2.) Navigate Menu

Each multi-page menu in the *Eliminator Next Gen* is denoted by dots at the bottom of the screen. The number of dots indicates the



Figure 2 - Eliminator Next Gen Menu

number of pages in the menu. The “white” dot indicates which page of the menu is currently displayed. To change pages, **swipe** your finger across the screen from left to right or right to left. See Figure 2.



Figure 1 - Eliminator Next Gen STAGE Buttons

### 3.) Quick Settings

From the Practice screen, press the “Left Lane” Settings or “Right Lane” Settings button to change: **Tree Type**, **Delay Box**, and **Roll Out**. Delay Box can also be changed by tapping the black box with green text at the bottom of the Practice screen




Figure 3 - Practice Mode Settings

From the Practice screen, press the “Settings” Button and swipe to page 2 to change between Dual and Single **User Mode**.

### 4.) Practice

In Practice Mode, press and hold the hand switches or STAGE buttons on the front of the Eliminator. Release after tree sequence to capture reaction time.