



594 Blackstone St., P.O. Box 206, Uxbridge, MA 01569
(508) 278-2189 Sales: Ext. 3 - Tech: Ext. 8

Instructions for Time Slip Printer - Auto Cut Used with Professional Ultimate Version 2.14 Only

The Auto Cut and Partial Cut features can be turned On or Off in the Time Slip Program:

- 1) Open the Portatree Main Screen
- 2) Click on the Time Slip Program button
- 3) Print Lines
- 4) On the Print Lines screen, you will see an area on the right-hand side where you can select or deselect these features.

